


# ZERØING TARGET



Invaluable when zeroing sights on any air weapon. Make a limitless number of shots and access the results immediately without the need to move from the shooting position.

Four independently moving indicator plates surround the centre spinner plate. When hit, the indicator plates show the centre of trajectory. Hit the centre spinner and the shot is on target.


Finally test correct sight alignment by hitting the small disc on the top of the spinner.

Also use to estimate windage and elevation adjustment in windy conditions.

#### Overall dimensions.

Height:	298.5mm (11 3/4")	Large disc:	44.5mm (1 3/4")
Width:	152mm (6")	Small disc:	25.5mm (1")
Depth:	127mm (5")	Plates:	54mm sq (2 1/8")

*Impact HIGH  
and LEFT*



*Impact LOW  
and RIGHT*



*Impact centre  
and on target*



Air Arms, Unit 6, Hailsham Industrial Park, Diplocks Way, Hailsham, East Sussex, England BN27 3JF.

Tel: 01323 845853. Fax: 01323 440573.

Website: [www.air-arms.co.uk](http://www.air-arms.co.uk)

Email: [general@air-arms.co.uk](mailto:general@air-arms.co.uk)